



3b) Insert the front tower wall pieces into the slot on the side wall of the front extension as shown.

4) While the glue on this part is still pliable add the tower side wall engaging both the slots and tabs in the adjoining walls as shown.

5) Once these joints have dried you can add the two short upper tower walls as shown.

6) The rear kitchen extension is constructed by gluing the two kitchen side walls to the rear kitchen wall, then gluing this assembly into the slots in the rear wall.

Tower Windows and Trim

7) Since the tower trim and window frames are all one piece, we will install the trim on the tower now. Center the tower window sashes in each window frame, then press the completed trim and window assembly into place on the trim sheet. Now press the tower trim into place with each window centered in its opening. Note that the vertical trim overlaps in the corners.

