

Windows

8) The window assemblies are all constructed in the same manner. First remove the peel-and-stick from the lower sash and apply a section of clear window glazing to it. Repeat with the upper sash and frame it being sure to keep the edge of the glazing flush with the top edge of the window. Now stick the lower sash into place on the frame. (For a little interest and variety it is possible to position the lower sash in an open position). Now take the outer window frame and remove the backing from it. Center the window sash assembly into the frame and press into place. It is best to place the various window assemblies into their openings as they are done, see the diagrams to the right for placement. The peel-and-stick on the frame will be enough to hold them into place.

Doors:

Remove the peel-and-stick from the door and apply the window glazing to the back of it as shown above. Now apply the front framework to each door, followed by the door trim making sure the sides and top of the door are centered on the trim and the bottom is flush. The doors are then applied into the walls. Refer to the diagrams to the right for the proper location of each door.

