



There are 4 door assemblies which are located on the front and rear of the house. For the front door remove the peel-and-stick from the inner door panel and apply the window glazing to the back of it. Now attach the outer door panel to the inner panel. Now apply the door frame to the door, keeping the door centered side to side in the frame and flush with the bottom edge. Insert the completed door into the door opening using the peel and stick backing on the door frame to hold it in place.

The other three doors will assemble the same but do not have clear glazing panels.

Corner Trim:

5) Apply the peel and stick trim one corner at a time. Each corner consists of a wide and narrow piece. Apply the narrow section first, flush with the edge of the wall. Now apply the wider trim section so that it overlaps the edge of the narrower piece to form an even corner.

Bay Window:

6A) Start by gluing the three triangular braces into the slots in the side of the house. Note that the top and bottom braces are the same with slots on the edge, but that the middle brace has tabs on it.

6B) Now glue on the bay window support walls starting with the center section first.

6C) Install the peel and stick outer bay window wall panels. Now apply the three pieces of upper trim boards. Lastly, remove the backing from the decorative trim pieces and apply the smaller one to the larger one, then apply these to the tops on the trim boards as shown.

6D) Apply the three windows into the openings as shown, followed by the upper roof panel.

