

LASER-ART STRUCTURES by BRANCHLINE TRAINS

Windows and doors:

2) We strongly recommend pre-painting all of the window components before assembly. The parts for the windows are on the trim sheets. Note that each wall section of this kit has its own trim sheet to make it easier to identify the parts. Note that the outer window frames for the bay windows are part of the large trim panels that cover the wall.

To assemble the windows, first remove the peel-and-stick from the lower sash and apply a section of clear window glazing to it. Now do the same with the upper sash and frame making sure to keep the edge of the glazing flush with the top edge of the frame. Now stick the lower sash into place on the frame. Note that it is possible to position the lower sash in an open position if desired. Now take the window frame and remove the peel-and-stick from it. Center the window sash assembly into the frame and press into place.

It is best to place the window assemblies into their openings as they are completed. See the diagrams for placement. The peel-and-stick on the frame will be enough to hold them into place.

The doors are built up from layers. Remove the backing from the outer door trim panel and apply it to the backing panel as shown. Mount the outer frame section to the door, then insert the completed door into the wall opening. Again, refer to the diagrams for placement.

Trim:

3) As with the windows, the trim for each side of the houses trim is located on individual sheets. Refer to the diagrams for placement.

Apply the trim one corner at a time following the diagram. Note that each corner consists of a wide and narrow piece. Apply the narrow section first, flush with the edge of the wall. Now apply the wider trim section so that it overlaps the edge of the narrower piece to form an even corner.

