

**Foundation:**

4) Remove the backing from each piece and apply to the lower areas of the store. Each piece has been cut and sized to fit into the appropriate area, see diagram for placement. Note that the foundation pieces on the rear of the house will have a space between them where the cellar doorway will be applied later.

Once the stonework is in place, paint it gray or brown. Spend a few minutes and pick out some of the individual stones with lighter and darker shades of your base color. Once this is dry follow with a wash of light gray or black to represent the mortar between the stones (Light gray will make the foundation appear newer, black - older). Finally dry brush some light gray or tan highlights into the stones.

**Subroof:**

5A) Glue the two large roof panels (marked "A" and "B") to the tabs on the walls. Panel "A" should overlap the other at the peak. Now add the two smaller sub roof panels to the rear extension of the house as shown.

5B) Glue the small center brace between the two roof panels marked "C" and "D", then glue the assembly to the tabs on the walls over the front bay.

5C) Glue the small center brace into the slot on roof panel "C" (installed in the previous step). Now glue sub roof panel "F" into place, sliding it onto the tab of the small roof support you just installed. Finally, add sub roof panel "E" to the adjacent panels as shown. Check the alignment, using some scraps of tape to hold everything in place while the glue dries. Any gaps between the panels will be covered by the roofing panels that will be applied later.

