



Foundation:

3) Install the stonework by removing the peel-and-stick backing from each piece and pressing them into place along the lower edge of each wall. Start with the sides of the house first, followed by the front and rear. The longer side pieces will overlap the shorter front and rear sections to give a flush corner.

Wait to paint the foundation until after all the pieces are in place (step 6A).

Trim:

4A) Starting on the sides of the house, add the trim that runs around the top of the foundation pieces. Remove the backing from each piece and press them into place just above the foundation pieces. Once the sides sections are in place, add the front pieces. These will overlap the sides to give you a flush corner. Note that there is a gap on the front and rear trim to allow for the placement of the porches.

4B) The corner trim is made up from two boards, one slightly wider than the other. Start by removing the backing from the thinner board and applying them to the side walls flush with the edges of the wall. Now apply the remaining trim boards so that they overlap the edges of the narrow boards giving a flush corner.

4C) Now apply the upper trim boards to the front and rear walls of the house. These should fit flush with the top edge of the roof.

Sub roof:

5A) Apply the two sub roof panels using the slots to locate them to the tabs on the front and rear wall panels.

