



Foundation:

4) Install the stonework by removing the peel-and-stick backing from each piece and pressing them into place along the lower edge of each wall. Start with the sides of the house first, followed by the front and rear. The longer side pieces will overlap the shorter front and rear sections to give a flush corner.

You can now paint the stone foundation with your choice of gray or brown paint. For added detail spend a few minutes to pick out some of the individual stones with lighter and darker shades of your base color. Once this is dry follow with a wash of light gray or black to represent the mortar between the stones (Light gray will make the foundation appear newer, black older). Finally dry brush some light gray or tan highlights onto the stones.

Trim:

5A) Starting on the sides of the house, add the trim that runs around the top of the foundation pieces. Remove the backing from each piece and press them into place just above the foundation pieces. Once the sides sections are in place, add the front pieces. These will overlap the sides to give you a flush corner. Note that there is a gap on the front and rear trim to allow for the placement of the porches.

5B) The corner trim is made up from two boards, one slightly wider than the other. Start by removing the backing from the thinner board and applying them to the side walls flush with the edges of the wall. Now apply the remaining trim boards so that they overlap the edges of the narrow boards giving a flush corner.

