



5C) Once your dormer is in place and dry, you can add the two main pieces of your plastic shingles. These will be applied by using the peel-and-stick backing on them.

House foundation:

6) The house's foundation consists of stone work as well as lattice woodwork around the porch areas. First you can attach the stone pieces by removing the peel-and-stick backing from them and pressing them evenly into place. Use the illustrations provided for locations. Once in place, you can add the woodwork pieces. These will be applied in the same fashion and will join tightly with the stone work. Holes in the lattice work should line up with the holes located in the bottom of the house walls. This will allow you to add the stairs in a later step.

House trim:

7) There are a few sections of outer house trim that can now be applied. These will attach to the house by removing the peel-and-stick backing from them. There is a larger and smaller piece for each corner. This will allow you to overlap the two pieces for a nice clean corner. Some of the trim work has angles cut into them to fit over the roof pieces and shingles. Use the illustrations provided for locations of each trim piece.

Additional roofing and shingles.:

8A) Locate the rest of the sub roofing pieces. The two larger pieces will glue into the tabs on the front wall section. The small window dormer and rear porch have thin panels which need to be folded slightly on the scribed areas before being placed on the house. Remove the backing and press firmly into place after folding.

8B) (Diagram on next page) You can now apply the rest of the roofing shingles to your house. These pieces will apply right over the sub roofing you just installed. Remove the backing from each piece and apply to the kit. Again, use the illustrations provided for placement.

Front and rear steps.:

9) (Diagram on next page) Locate the four stair stringers and glue them into the slots provided in the front and rear porch area. Once in place, you can add the top steps to them. These will be applied by removing the backing from each step and placing them into each stair stringer.

