



House trim:

3) Locate the house trim on the 1/64 trim sheet. Starting with the peel-and-stick trim for the sides of the house, place the trim on the siding starting with the peak of the house and making sure the sides line up with the sides of the house walls. Once in position, press trim into place. Note that the bottom of the trim will be slightly above the base of the house to allow for the foundation pieces that will be applied later. Once both sides are in place you can apply the front and rear trim pieces. These trim pieces will be applied in the same manner as the sides. These trim pieces will fit in between the side trim sections to form tight corners. Once the trim sections are in place you can add the decorative trim to the top of the house as shown. These will be placed on top of the other trim work you installed previously. Once these are in place you can apply the 4 smaller decorative pieces to the sides of the house to match the front and rear ones.

Base and Porch Flooring:

4) Glue the two sections of flooring together as shown. Be sure you glue the flooring with the scribed deck details facing up. Once dry, you can glue your house to it. Your house walls have tabs located on the bottoms of them. These will fit into holes in your flooring piece. Line everything up and glue them into place.

Porch Assemblies:

5) The front porch has two side pieces of decorative lattice as well as an overhead awning. Mount the two side lattice pieces (found on the lattice trim sheet) into the side walls with the tabs on each piece making sure the two other tabs are facing upward. These tabs will fit into the slots in the overhead awning. The flat bottom of the lattice fit into the slots of the flooring.

Now add the triangular roof support (found on the 1/64 trim sheet) as shown, followed by the sub roof (also on the 1/64 trim sheet). The sub roof panel is designed to be folded along its centerline as shown. Next, add the front trim to the awning by first applying the outer trim to the triangular decorative panel, then mounting this assembly to the triangular support section as shown.

The side porch is constructed by first folding the latticework on the two scribe lines to form the front and two side walls of the side entrance. These will fit into the tabbed holes in the flooring. These are peel-and-stick pieces but should be glued along the bottom edge as well for extra support.

Next, glue the triangular roof support from the base sheet to the porch sub-roof as shown. Once the glue is dry install the flat sub-roof to the latticework. Once this is in place and glued to the house, remove the peel-and-stick sub roofing from the lattice trim sheet. Fold this piece on the scribed lined and apply to the top of your flat roof piece as shown.