



**Window shutters:**

5) There are 5 sets of window shutters for this kit - 4 of them are for the larger windows on the sides and front of the house. The two smaller ones will accent the upper dormer side windows. Apply each to the window frame using the peel-and-stick adhesive. Make sure the decorative hole in the shutter is at the top when applying each shutter.

**Front porch:**

6) Paint the porch pieces ahead of time as it will be difficult to get to all areas once it is installed. Locate the floor of the porch and install with the etched planking face up. Using white glue, glue the porch railing into the proper hole in the porch flooring. Then place and glue the porch railing into the holes in the house.

**Trim:**

7) Locate the side trim pieces on the trim sheet. Each corner is made from 2 trim pieces. One trim piece is wider than the other. Remove the peel-and-stick backing from each piece, press the narrow strip in place followed by the wider strip. The wider trim strip should overlap the edge of narrow strip presenting a nice clean corner. Repeat for all 4 corners of the house.

**Sub Roofing:**

8A) Add the front and rear sub roofing to your house kit using white glue. The roof panels will fit onto the tabs on each side of the house walls. The upper front section of the house will fit up through the hole in the front roof panel - see diagram.

8B) Locate the 2 upper side walls and glue into the slots in the sub roof as well as the tabs on the front wall. Note the positioning from the diagram. The notches fit into the tabs on the front upper wall.

