



**Roof shingles:**

9A) Add the plastic roofing to the sub roof panels. Remove the peel-and-stick backing from each panel and press into place evenly. Start with the front roof panel for the house. Carefully place the shingle sheet over the front sub roof making sure that it fits tightly against the front window section. (See diagram). Once the front panel is applied add the rear section. The two panels will join together at the top to form a tight joint.

9B) Now add the upper sub roof panel to the dormer. This will glue onto the top tabs of the walls installed in step 8B above. Once in place, apply the other section of shingles. This shingle piece should run up into the other shingle panel applied earlier.

**Steps:**

10) The front and rear step assemblies are constructed in the same manner. Locate and glue the two stringers into the holes located in the foundation strip. Add adding the steps to the tops of each one. Steps are applied by removing the peel-and-stick and pressing to the stinger top surface.

**Roof caps and chimney:**

11) Plastic strips are included in the kit to be used as roof caps. Cut these to size and glue into place with plastic cement along the top peaks of the roof panels as shown. You can also place a strip along the edge of the area where the dormer and main roof shingles meet.

A resin chimney has been supplied with your kit. This can be located on the top rear center of the roof by either cutting a hole in the sub roof and placing the chimney inside, or sanding the proper angle into the bottom of the chimney and attach with cement. Use any extra plastic strips from your roof to trim out the bottom edges of the chimney as well.

