

Constructing the shell:

1A) Start by gluing the front and rear walls of the front section to the small side wall as shown. Now do the same with the smaller back section. Make sure both sections are square and set aside to dry.

1B) Tab and glue the larger side wall to the two sections to it as shown. Again, make sure each section is square and set aside to dry.

Trim:

General) Apply the trim by removing the peel-and-stick backing from each piece then pressing it into place on the structure. The peel and stick adhesive allows the part locations to be adjusted slightly when first applied, but will set up to a permanent bond in a few hours.

2A) Start by applying the upper trim sections to the top edges of each side as shown. Next add the front and rear sections. These will slightly overlap the side sections to give a neat corner.

2B) Install the corner trim boards. Each corner will have two trim boards, the front and back boards will overlap the side boards. Note that on the front wall, one trim piece is notched to allow for the stonework piece to be applied in a next step. There are also two trim boards to fill the inner corner between the two sections. See diagram for placement.

Front Brickwork:

3) Paint the brick panel before application.

The stonework sheet can be added by removing the backing, then pressing it into place on the front of the stand. Make sure you keep it above the notches cut in the bottom of the front wall.

