









For some added detail you can pick out individual shingles with slightly lighter or darker shades of and once this is dry brush the shingles with some highlights. vertical streaks of a lighter color to pick out the the base color. Finally, add a thin wash of black

highlights to help pick out the shingles. red single roofs. You can also add some dry brushed Paint your roof now. Many Santa Fe stations had

Chimneys and vent pipes:

can either be sanded to match the roof angle and roof and the chimney placed into it. cemented to the roof, or you can cut a hole into the inside. Now add the main chimneys. The chimneys roof and inserting the tube, cemented it from the 9) The two styrene tubes are for use as vent pipes. These can be added by drilling a small hole in the



aside to dry. shown. Make sure the walls are square and set 10A) Glue the four wall sections together as

to the outhouse. 10B) Now add the two small upper wall sections

hold them into place. them into the openings using the trim adhesive to Next, assemble the two outhouse doors and insert 10C) Apply the trim to the outhouse as shown.

10A

shown. 10D) Glue the subroof panels into place as

paper has been supplied for the flat section of the did with the station. A pre-cut section of roofing 10E) Add the roofing paper to the outhouse as you

where desired... the kit. Cut these off the sheet and glue into place We have included some appropriate signs with



