



**Chimney:**

9) Sand the bottom of the resin chimney at a slight angle to match the lower back roofline. Paint the chimney now. When dry, the chimney can be placed down through the hole in the roof and cemented to the back wall of the tower between the two upper sets of windows. See diagram.

Your kit is now completed and ready to for your layout. We hope you've enjoyed this kit. If you have any problems or comments, please contact us at:

**Branchline Trains**

333 Park Ave. East Hartford, CT. 06108

For a full list of our products, see our web site at [www.branchline-trains.com](http://www.branchline-trains.com)

