



Roofing trim:

9) The two trim boards can now be added to the edges of the sub roof panels. Apply these by removing the backing paper and pressing them into place.

Roofing:

10) Slotted paper strips have been supplied with your kit to represent the roof shingles. Apply these using white glue, starting at the bottom edges. As you work your way up the roof overlap each row and stagger the joints between each strip. Once you reach the top of each roof section, use a blank strip to simulate a roof cap.

Once the shingles are in place paint them to match your desired shingle type. For wood shingles start with a dark brown paint, for slate a dark gray (weathered black works well). Once the main color is dry dry-brush some lighter highlights onto the roof, streaking it from top to bottom. A few light passes with slightly different colors will really make the shingles pop.

