



Upper dormer:

8) Using white glue, assemble the dormer front and two dormer side walls and attach them into the slots in the sub roof as shown. Now add the window assembly and side trim pieces.

Tar paper roofing:

9) Black paper has been supplied with your kit to represent tar paper. These are precut into strips for you. Starting at the bottom of each roof section, overlap each piece of paper as you work your way up the rooflines. You can fold the top piece of roofing to use as a roof cap. The paper can be painted a dark gray, and drybrushed for a bit of weathering. You may also want to add black lines painted on the joints to represent tar sealer.

Stairs:

10) The front and rear stairs both assemble the same. Glue the two stair stringers into place followed by adding the steps to the tops of each one. Steps will apply by removing the peel-and-stick backing from them.

Chimneys:

11) A resin chimney and styrene smokestack have been supplied with your kit. These can be placed wherever you want them, we have left the locations up to you. The resin chimney can be located on the top rear center of the roof by either cutting a hole in the roof or by sanding the base of the chimney to the proper angle into the bottom of it and attaching it to the roof with cement. The styrene tube can be installed by drilling an appropriately sized hole in the roof.

Your kit is now completed and ready to display. We hope you've enjoyed this kit. If you have any problems or comments, please contact us at:

Branchline Trains

333 Park Ave. East Hartford, CT. 06108
(800) 289-4000

For a full list of our products, see our web site at
www.branchline-trains.com

