

**Foundation (continued):**

Once the stonework is in place, paint it gray or brown. Spend a few minutes and pick out some of the individual stones with lighter and darker shades of your base color. Once this is dry follow with a wash of light gray or black to represent the mortar between the stones (Light gray will make the foundation appear newer, black - older). Finally dry brush some light gray or tan highlights into the stones.

**Subroof panels:**

7) The two lower peel-and-stick sub-roof panels mount onto the tabs on the lower side walls. The upper peel-and-stick sub-roof panel needs to be folded slightly on the scribed line before installing.

**Unloading shed:**

8A) Glue the four wall sections together as shown. Check that they are square and set aside to dry.  
 8B) Apply the peel-and-stick sub roof panel onto the top of the wall sections.  
 8C) Apply the corner trim as shown, overlapping the corners on each section as you did on the main structure.

8D) The unloading shed can be installed either flush with the bottom of the main building or on an elevated ramp. If you choose to use a ramp you will need to build up the scenery around the building to provide one. In this case you will probably want to leave the loading shed off the main building until you install it on the layout. If you're planning to do a flat installation the loading shed can be glued to the side of the main building now. See the diagram.

**Roofing and Loading Chute:**

9A) A sheet of black tar paper roofing strips is included with your kit. Glue these on the roof using white glue, overlapping each slightly over the previous one as you go.

